



CP-TEL On Demand Instructions

Please note: You must call the CP-TEL office to activate your free On Demand account before you can rent an On Demand title.



GO TO SETTINGS

Press **Settings** on your remote to view the Options tabs at the top of your television screen.

CHOOSE RENTALS

Using the navigational **arrow keys** on the remote, point to Rentals on your television screen and press **Select** to display a menu list of categories.

SELECT A TITLE

Using the arrow keys, browse through the categories and titles. Highlight the title you want to view and press Select.

RENT

Once you have selected a title, a pop-up window will appear with the option to Rent or Cancel. Using the arrow keys on your remote, point to Rent and press Select to bring up the Rental Confirmation page. Enter your PIN, point to Rent, and press Select. You will also have the option to Rent or Cancel at this time.

To share the selection with other TVs in your system, check the Share box, other wise the rental will only be on the set you're watching.

Program Controls slide down the cover at the bottom of the remote to reveal the program function controls (Pause, Stop, Forward, Reverse, etc.). Pushing the CBL or VCR button at the top of the remote will enable these controls.

On Demand Categories Menu:

- All - Displays titles from all movie categories in alphabetical order
- Just In - Lists titles recently added
- New Releases - Lists newly released titles
- Movies By Category - Displays movie categories menu (All, Action, Comedy, Drama, etc.)
- Free On Demand - Displays menu of content available for no charge (All, Karaoke, Kids Unlimited, Music Unlimited, etc.)
- Movies On Demand - Displays menu of movie categories (All, By Category, EuroCinema, Free Extras, etc.)
- Events On Demand - Displays menu of event programming (All, Mature Events, Ring Sports, Specials, etc.)
- Adult - Displays menu of adult programming choices.
- By Category - Displays menu (All, All Movies)

It's not cable. It's not satellite.
It's better.